

MLSP Quick Start Guide

1. Verify you have the following items:

Item	Quantity
MLSP Series Synthesizer	1
Heat-sink and a Fan (Recommended)	1
DC Power wire harness and mating connector	1
USB A male to USB Mini-B cable	1
CD Rom (Contains manual, quick start guide and PC software)	1

2. Place unit on the heat-sink and turn on the fan.

3. Connect an external reference frequency (if required) to J3 (i.e. 10.0 MHz Ref. out from test equipment).

4. Connect a +5.0 VDC and a +15 VDC power supply with adequate current to operate the product (see spec sheet) to the J1 connector; +5.0 VDC on J1 pins 5 and 6, +15.0VDC on J1 pins 1 and 2 and a common ground for both supplies on J1, pins 3 and 4.

5. Connect the RF output port J4 to the desired measurement equipment (Frequency counter, Spectrum analyzer, etc.).

6. Turn on power supplies and allow a 5-minute warm-up.

7. Install the CD:

The CD Rom supplied with the package contains a **SetupMLSP.msi** file, that when executed, will create a folder named "MLSP Support Files" on the desktop containing short cuts to the manual, documentation and programs for interfacing the product with a personal computer. This **SetupMLSP.msi** file is compatible with Windows XP, Windows Vista and Windows 7. The most current versions of these files, new offerings and filter specifications can be downloaded at our web site: <http://www.microlambdawireless.com> .

8. Quick Remote Control using the USB interface:

Connect the unit to the PC's USB port using the supplied USB cable. Wait for Windows to verify that the device was successfully installed. From the folder on the PC desktop, run the program named "MLSP PC Interface". A control interface should now be visible with information about the product. Commands may be sent to the unit and information received from the unit, using this program. See the Help menu for more information.